

HTS05 Systems

For ceramic processes



...where experience counts!

PhoenixTM HTS05 Systems for ceramic processes

Data Logger

PhoenixTM data loggers are designed for use in harsh industrial environments. The electronics are protected by a robust, water resistant, machined aluminum case. . Optional two way RF telemetry is available, allowing real time data analysis and for the data logger to be reset and downloaded remotely. All loggers are shipped with a factory calibration certificate traceable to national standards. Optional certification to UKAS (UK) or DKD (Germany) can be supplied if required. For convenience and future reference, a copy of the original calibration certificate and the calibration data are stored within the data logger and can be accessed as required.

Type No. of channels Thermocouple type	РТМ1-006НТ, РТМ1-010НТ, РТМ1-020НТ 6,10 or 20 K, N, R, S or B		Process Temperature Measurement	
Thermocouple Type	Measurement range	Accuracy	F	
K	-148°F to 2498°F -100°C to 1370°C	+/- 0.5°F +/- 0.3°C		
Ν	-148°F to 2372°F -100°C to 1300°C	+/-0.5°F +/- 0.3°C	Two way radio transmission as an	((c))
R	32°F to 3200°F 0°C to 1760°C	+/- 1.3°F +/- 0.7°C	option	$(((\mathbf{q})))$
S	32°F to 3200°F 0°C to 1760°C	+/-1.3°F +/- 0.7°C		
В	122°F to 3299°F 50°C to 1815°C	+/-5.5°F at 750°F, +/-1.8°F at 730°F +/-3.0°C at 400°C, +/-1.0°C at 500°C	1	
Resolution	0.2°F/0.1°C		Robust and waterproof housing for reliable use in hostile environments	SAL

Max operating temperature Battery type Sampling rate Memory Start trigger Dimensions

230°F/110°C

2 x replaceable lithium (AA) Adjustable from 0.2 sec. to 1 hour Up to 3.8M data points non-volatile memory Time, temperature, start button or software 0.79"x3.85"x7.87"(h x w x l) 20 x 98 x 200mm



Standard batteries: 1000h measurement time, widely available



What is temperature profiling?

All industrial ovens or kilns use thermocouples to control the zone temperatures. However these thermocouples measure only atmosphere temperature in their respective zones and do not indicate the true temperature of the product, which is vital to ensure the heat treatment specification is adhered to.

PhoenixTM can provide a solution:

Our monitoring system travels through the kiln with the product, logging temperatures from up to 20 thermocouples connected to the product or distributed in the load to get an accurate thermal 'balance'. The system is easily placed on the line with the product causing less disruption and gives a more accurate picture of true product or load temperature. At the end of the profile run a powerful software package analyses the logged data to determine whether the specification has been met.

The profiling trials can be quickly carried out allowing you to resolve any kiln problems quickly, and to provide your customers with an assurance of a consistent process control.



PTM1220





TS05 thermal barriers

Standard TS05 range performance:

Developed for the ceramic industry, the PhoenixTM TS05 series Thermal Barriers travel beneath the kiln car for a sustained period at moderate to high under car temperatures. Built from high grade stainless steel these Thermal Barriers use evaporative water technology to keep the Data Logger cool and protect against mechanical damage and the dusty environment of a ceramic kiln. These thermal barriers have detachable thermocouple sockets which can be mounted remotely from the thermal barrier for easy thermocouple fitting.



Stainless steel evaporative thermal barrier with microporous insulation and dual thermocouple exits for use with 20 channel data loggers



* for a 20 channel data logger

Need a thermal barrier to suit your application? Tell us your requirements, and if it's possible, we'll design and manufacture it for you! We are constantly developing and looking forward to any new challenge.

Thermocouples

All Phoenix TM thermocouples are manufactured using the highest quality materials and conform to ANSI 96.1 special limits specification. For type K, mineral insulated thermocouples are generally the first choice. The thermocouples wires are insulated by magnesium oxide and protected by a high grade alloy sheath. For special applications we can supply thermocouples with other insulation materials.



The use of water evaporation as a cooling medium allows very compact dimensions and high thermal performance.

High temperature materials and

highest quality workmanship!

Thermocouple sockets can be mounted separately for easy access.



Thermocouples can be mechanically held, or retained in holes to record temperatures at critical points.

Type K or N thermocouples in 1/16", 5/64" or 1/8" (1.5, 2 or 3mm diameter.)





Thermal View Plus

The easy way to get a perfect result!



Simply enter:

- How to start the data logger
- The rate at which data is to be collected
- The number of thermocouples to be used.

For regular measurements these can be set with one mouse click or pressing the data logger start button.



Comprehensive analysis tools are located on the left side of the screen for single click analysis and report generation. Data import and export in both .csv and PhoenixTM formats are available allowing electronic transfer of process data.



The temperature profile is displayed in the graphics window of the Thermal View software. Thermocouple profiles can be switched on or off individually and you can zoom in for more detailed analysis.



User defined kiln zones and kiln features to support profile analysis.

Contact us for a demo version!

PhoenixTM LLC 4600 140th Avenue North, Suite 180, Clearwater FL 33762 USA



www.Phoenixtm.com Tel.: +1 (727) 608 4314 info@phoenixtm.com